



Ozone-Safe Ultrasonic Caustic-Free Alkaline Liquid Cleaner



Description

Chem-Crest 211 is a multipurpose heavy duty caustic-free and phosphate-free alkaline liquid cleaner. It is useful in many applications demanding removal of heavy contaminants. Chem-Crest 211 is a biodegradable, concentrated detergent.

Substrate Compatibility

Chem-Crest 211 is safe on cast iron, steel, brass, aluminum, copper, beryllium copper, stainless steel, glass, plastics, silicon wafers and ceramics when used as directed.

Typical Contaminants Removed

Chem-Crest 211 removes airborne contaminants, heavy oils, greases, fingerprints, tripoli, lubricants, ceramic dust, light buffing and lapping compounds, light silicone oils and ink markings.

Operating Concentration

Chem-Crest 211 is typically used at 3-10% volume in ultrasonic applications. Normal operating temperatures: 120°-170°F. Recommended rinse water temperature: 120°-150°F.

Disclaimer: All statements, technical information and recommendation contained herein are based on tests or other information available to us which we believe to be reliable, but the accuracy or completeness thereof is not guaranteed and are made without representation or warranty. They are presented for your own investigation and verification. Products discussed are sold without warranty, expressed or implied, in law or fact and upon the condition that purchasers make their own tests to determine the suitability of such products to their particular purpose. We shall not be liable for any injury, loss or damage direct or consequential, arising out of use or the inability to use the product. It is the user's obligation and responsibility to determine that any use of the product or the information may infringe on patent rights.



CREST ULTRASONICS • PO Box 7266 • Scotch Road • Trenton, NJ 08628
609-883-4000 • Fax-609-883-6452 • WWW.CREST-ULTRASONICS.COM

Storage

Avoid freezing conditions.

Disposal Methods

Dispose of in accordance with Federal, State and Local Government regulations.

Safety Precautions

See Material Safety Data Sheet.

Availability

Chem-Crest 211 is available in cases of 4x1 gallons and in 55 gallon containers.

Physical Data

Flash Point: None
Specific Gravity: 1.08
pH: 5% solution = 11.5+/-0.5
Solubility in Water: Complete
Volatiles: N/A

**These values do not constitute specifications*

India Office

Crest Ultrasonics India Pvt Ltd • C-11, Functional Industrial Estate • Patparganj • Delhi 110092 • INDIA
Phone (91) 11 22164532 • (91) 98100 33631 • info@crestultrasonicsindia.com • www.crestultrasonicsindia.com